

## control box kit

Deluxe Dual Binnacle Control Box includes the same features as the Single Binnacle Control Box, plus a unique base mounted PTT system allowing you to trim the motors individually then adjust them together for maximum performance. Kit includes items listed. \*Main Wiring Harness must be ordered separately.

67000-93J14*	Dual Binnacle Control Box Kit – Includes:
37100-96J11	Dual Ignition Switch with Emergency Stop
38500-93J00	Warning Buzzers (2)
67200-93J23	Deluxe Dual Binnacle Control Box Assembly

## deluxe single binnacle control box kit

Deluxe single Binnacle Control Box uses a convenient thumb-operated power trim and tilt switch, push-button shifting disengagement for faster warm ups and built-in neutral safety switch. Kit includes items listed. \*Main Wiring Harness must be ordered separately.

67000-93J04*	Single Binnacle Control Box Kit – includes:
37100-96J23	Ignition Switch Panel with Emergency Stop and Warning Buzzer Assembly
67200-93J13	Deluxe Single Binnacle Control Box Assembly

## deluxe flush mount binnacle control box kit

Suzuki's top quality Flush Mount Control Box features include a smooth action, thumb control power trim and tilt switch, a push button to disengage the shifting for faster warm-ups and a built in neutral safety switch. Reversible for left hand installations. Kit includes items listed. \*Main Wiring Harness must be ordered separately.

67000-93J21*	Flush Mount Binnacle Control Box Kit – Includes:
37100-96J20	Ignition Switch Panel with Emergency Stop and Warning Buzzer Assembly
67200-93J30	Deluxe Flush Mount Control Box



## miscellaneous components

38500-93J00	Warning Buzzer. Replacement Warning Buzzer for DF models.
36620-93J20	Control Box Adaptor. Adapts 2005+ model control box with square connector to 2004 and earlier motors with round connector.
36620-93J30	Wire Harness Adaptor. Adapts 2005+ model engine with square connector to 2004 and earlier harness with round connector.
67500-93J00	Single Binnacle Control Box Spacer
67500-93J10	Dual Binnacle Control Box Spacer

67200-91J01	DF4/6	·03 – ·10
67200-89E32	DF9.9/15	'97 <b>–</b> '04
67200-94J12**	DF9.9/15	'05 – '10
	DF8A/9.9A	'10 – later
	DF25 V-Twin	'06 – later
67200-99E52	DF25/30	'00 – '04
67200-94J12*	DF25/30	·05 – ·08
67200-99E53	DF40/50	'99 <b>–</b> '04
	DF60/70	'98 <b>–</b> '04
	DF90/115/140	'01 <b>–</b> '04

DF40/50	·05 – ·10
DF40A/50A/60A	'10 – later
DF60/70	'05 – '10
DF70A/80A/90A	'10 – later
DF90/115/140	'05 – later
DF150/175	'06 – later
DF200/225/250	'05 – later

\*Requires 36620-93J01: 21' Main Wire Harness, 36620-93J51: 16' Main Wire Harness, 36620-93J61: 26' Main Wire Harness.

\*\* Requires 36620-94J01: Main Harness





Assembly. Includes wiring, hardware

and stop switch lanvard.

hardware and lanyard.

Emergency Stop Switch Panel Assembly. Includes wiring,

P.T.T. Switch Panel Assembly. Includes wiring and hardware.

37803-93J03

37805-93J00

37141-99E00

37141-99E10

37141-99E20

37141-99E30

KEY (931)

KEY (932)

KEY (933)

KEY (934)

37141-99E60

37141-99E70

37141-99E80

37141-99E90

KEY (937)

KEY (938)

KEY (939)

KEY (940)

99105-11001-016

99105-11001-017

99105-11001-018

99105-11001-019

16'

17'

18'

28'

29'

30'

99105-11001-028

99105-11001-029

99105-11001-030