SUZUKI D7300 precision control BUZUKI 67200-98J02 single engine spc box SUZUKI 67200-98J12 dual/tripple engine spc box



electronic throttle and shift systems for DF300

Suzuki Precision Control (SPC) offers DF300 boaters the latest in technologically advanced control systems. Suzuki Precision Control is a computer-based electronic "Fly-by-Wire" system eliminating mechanical control cables. While you enjoy smooth, friction-free throttle operation, the system's computer is processing and transmitting commands in real-time to actuators at the engine delivering precise throttle control with smooth, decisive shifting.

36770-98J00

36775-98J00

36776-98J00

37100-98J00

37100-98J20

38500-93J90

67200-98J10

09403-13402

37803-93J03

09407-08401

33925-93J00

33926-98J00

36621-98J10

36622-98J00

36623-98J10

36624-98J10

36625-98J00

36770-98J00

36775-98J00

36776-98J00

37100-98J00

37100-98J30

37803-93J00 38500-93J90

67200-98J10 09403-13402 **BCM Unit**

BCM Holder-L

BCM Holder-R

Warning Buzzer

Harness Clamp

Buzzer Clamp

ECU Cushion

Battery Wire

BCM Holder-L

BCM Holder-R

Warning Buzzer

Harness Clamp

BCM Unit

Resistor Terminal (2)

Triple Engine Harness Assembly

Dual Station Main Harness Assy

Main Switch Panel Assembly

Emergency Stop Panel Assembly

Dual Engine Remote Control Assembly

Triple Panel Assembly

BCM No.1 Harness Assembly for Triple Engine Single Station

BCM No.2 Harness Assembly for Triple Engine Second Station

triple engines SPC kits

Main Switch Panel Assembly

Dual Engine Remote Control Assembly

Dual Panel Assembly

Emergency Stop Switch

SPC box only (replacement units)

67200-98J02	Single Engine SPC Box only
67200-98J12	Dual and Triple Engine SPC Box only
67200-98J21	Flush Mount SPC Box only

flush mount SPC kit

67000-98J60-001	Flush Mount SPC Kit – Includes:
09407-08401	Buzzer Clamp (1)
33925-93J00	ECU Cushion (1)
33926-98J00	Resistor Terminal (2)
36623-98J00	BCM No.1 Harness Assembly for
	Single Engine Single Station
36625-98J00	Battery Wire
36770-98J00	BCM Unit
36775-98J00	BCM Holder-L
36776-98J00	BCM Holder-R
37100-98J00	Main Switch Panel Assembly
37100-98J10	Single Panel Assembly
38500-93J90	Warning Buzzer
67200-98J20	Flush Mount Remote Control Assembly
37803-93J03	Emergency Stop Switch

33925-93J00	ECU CUSNION (1)			
33926-98J00	Resistor Terminal (2)			
36622-98J00	Dual Station Main Harness Assembly			
36623-98J00	BCM No.1 Harness Assembly for Single Engine Single Station			
36624-98J00	BCM No.2 Harness Assembly for Single Engine Second Station			
36625-98J00	Battery Wire			
36770-98J00	BCM Unit	•		
36775-98J00	BCM Holder-L			
36776-98J00	BCM Holder-R	•		
37100-98J00	Main Switch Panel Assembly			
37100-98J10	Single Panel Assembly			
38500-93J90	Warning Buzzer			
67200-98J00	Single Engine Remote Control Assy			
33911-88BL0	BCM Connector Cap			
09403-13402	Harness Clamp (10)			
37803-93J03	Emergency Stop Switch			
dual engi	nes SPC kits	67000-98J20-001 Single Station SPC Kit	67000-98J30-001 2nd Station SPC Kit	
09407-08401	Buzzer Clamp			
33925-93J00	ECU Cushion			
33926-98J00	Resistor Terminal(2)			
36621-98J00	Dual Engine Harness Assembly			
36622-98J00	Dual Station Main Harness Assembly		•	
36623-98J10	BCM No.1 Harness Assembly for Dual Engine Single Station	•		ľ
36624-98J10	BCM No.2 Harness Assembly for Dual Engine Second Station			
36625-98J00	Battery Wire	•		

67000-98J00

Single Station SPC Kit

(15)

67000-98J40-002

Single Station SPC Kit

67000-98J17

2nd Station SPC Kit

(10)

67000-98J50-002

2nd Station SPC Kit

SUZUKI DF300 precision control



37100-98J11

single engine control panel



37100-98J21

dual engine control panel



37100-98J02

main power switch



37803-93J03

emergency stop switch

